



TRACKS SHORTENING INSTRUCTIONS

To always insure that your Eco-Tracks have the right tensity, we provide an easy solution to shorten your tracks. Natural wear will cause any bogie tracks to loosen, however shortening the tracks will increase the lifespan and capacity of your product.




Example 294-644421 EVO-Soft 710 x 26.5"

STEP 1




STEP 2



Small track lock

STEP 3




Large track lock




Remove 1 pcs
of crossbar and link

STEP 4



**IF FURTHER SHORTENING IS
REQUIRED REPEAT STEP 1-4**



**EcoTracks
Country**

Olofsfors
Make your own way